

UMG604->512 - Messbereichseinstellung Transienten / Events

Betrifft: UMG604,605,508,509,511,512

recording range of event/transient UMG meters

meter	event recording		transient recording	
	Pretrigger	Posttrigger	Pretrigger	Posttrigger
UMG 508	64-6000	64-6000	64-8192	720-8192
UMG 509	64-6000	64-6000	64-8192	720-8192
UMG 604	64-6000	64-6000	64-8192	720-8192
UMG 605	64-6000	64-6000	64-8192	720-8192
UMG 512	32-6144 (half wave)	32-32000 (half wave)	64-8192	720-32000
	360-65536 (points)	720-65536 (points)	64-8192	720-32000